
Installation Bulletin

BULLETIN NO: 409

APPLICABLE TO: DM 441B DME Interrogator

SUBJECT: Differences between unit flavors in activating the HOLD function

There has been some confusion about the HOLD functions on the DM 441B. This bulletin describes how the HOLD function is activated in the different flavors.

On a DM 441B P/N 066-01107-00, -01, -02, -10, -11, the HOLD functions are activated by a momentary GND. On a DM 441B P/N 066-01107-12, the HOLD functions are activated by a latched GND (for use with a KDI 572).

Also, concerning 429 HOLD operation, a DM 441B P/N 066-01107-00, -10, -11 cannot be put into HOLD via the 429 bus. A DM 441B P/N 066-01107-01, -02, -12 can be put into HOLD via the 429 bus.